

Yamaha FX HO 2012-2018 Instructions

For the best support, please watch our installation video on our website here:

<https://highsurfrescue.com/portfolio/strap-kit/>

Download color copy at <https://highsurfrescue.com/resources/>



*****Note:** keep all buckles on port (left) side of ski.

Extra washers should be used as backing washers inside hull for all rivets.

Provided: Straps & Hardware

Needed: Drill, 3/16 Drill Bit & Rivet Gun

#1 - #4 Straps denoted in the order that they are attached to the ski from bow (front) to stern (back)

STEP #1

Hole in #1 strap sandwiches in hatch. Loosen bolt in photo, slide strap in between plastic and align hole with bolt. Re-fasten bolt. Close hatch, with strap dangling, place bracket parallel with the hatch. Using the brackets, mark holes where drilling is needed. Drill holes, attach rivets and repeat for opposite side.



STEP #2

Align the #2 strap by placing the strap over the glove box. Align ends that will be riveted with trim on each side. Using strap mark holes where drilling is needed. Drill holes, attach rivets and repeat for opposite side.



STEP #3

Align the # strap (with handle) on the rear of the front seat. Level bracket, using bracket mark holes where drilling is needed. Drill holes, attach rivets and repeat for opposite side.



STEP #4

Align the #4 strap on the rear of the rear seat. Using strap, mark holes where drilling is needed. Drill holes, attach rivets and repeat for opposite side.

