




HSA Slick Skin Ding Repair Guide



*****If you are unsure about damage, please refer to us first by sending an email and photos of damage to info@highsurfrescue.com**

What you will need:

- 1 tube of Sashco clear Lexel Caulk Polymer Sealant (available at Walmart or your local hardware store)
 - <http://www.sashco.com/products/lexel/>
- Popsicle Stick (optional)

How to repair your sled:

Step 1:

Clean surface of salt, sand, moisture, etc...

Step 2:

When dry, fill hole with Lexel sealant

Step 3:

Use popsicle stick or finger to shape and smooth sealant to surface. Finish and let dry

High Surf Accessories, P.O. Box 1147, Haleiwa, HI 96712
P:(808) 638-5952 F: (888) 558-8507 E: info@highsurfrescue.com
www.highsurfrescue.com